Video disk type

TYPE	RECORD FORMAT	HORIZONTAL DEFINITION	RECORD CONTENT	DISK SIZE
DVD	MPEG2	⩾500 LINES	Audio+Video	12cm/8cm
VCD	MPEG1	⩾240 LINES	Audio+Video	12cm/8cm
CD	DIGITAL	——	Audio	12cm/8cm
MP3	DIGITAL	——	Audio	12cm/8cm
MP4	MPEG4	⩾240 LINES	Audio+Video	12cm/8cm
MP5	AVI	——	Audio+Video	12cm/8cm
WMA	DIGITAL	——	Audio	12cm/8cm
JPEG	——	⩾500 LINES	Picture	12cm/8cm

Accessories

ITEM NO	DESCRIPTION	QTY
1	7" TFT LCD Pillow Monitor	1
2	Wireless Remote Control +Joystick	2-in-1
3	Wireless Joystick	1
4	Assembling Stick	2
5	User's Manual	1
6	Warranty Card	1

BOOSTER®

BM-7700PLDVD

TFT LCD Monitor

OPERATION MANUAL

⚠ Warning

- Read this manual before using this product.
- This product is composed of precision components and should not be dissembled Service must be perfurmed by a factory authorized technician.
- Protect the product from moisture and shock.

Product installed



The adjustable steel pipe bracket to be left and right movements of moving to suit different types of cars installed.

How to use the Headrest monitor

Thank you for choosing this monitor for your mobile entertainment system. To ensure long-term trouble-free service of the product, please read this Manual carefully before using the monitor.

Operation for Game Function

The player features superior intelligent game function,it will make you enjoy the wonderful game time.

Operation for game function

1.Description for built-in game operation
On the no disk or stop playing status,press SETUP on the function controller or press select on the game controller enter the menu,use direction key select EMBEDED game or NATIVE game and press ENTER on the function controller or START on the game controller to enter the game.

2.Description for playing the Game Disk Operation
(1) Press Eject key and load the game disk(the Disk for free),the game main menu will be displayed in seconds
(2) Press direction key of the function controller or game controller to select the games then press ENTER on the function controller or press START on the game controller to enter the gmae.

3.Description for the Wireless Game Controller
(1) Press SELECT to enter the menu of the built-in games.
(2) Press direction key to select the games you like,then press the START to enter the game.
(3) Enter the game,press the direction key to select upward/downward/leftward/rightward,press A.B,TA and TB key to operate the functions.

(4) Press Stop/Return key on the function controller or press RESET key on the game controller to exit the game.
if enter EMBEDED game,press stop/return key or press RESET key can return to the main menu,then use kirection key select EXIT and press ENTER on the function controller or START on game controller to exit the game.



1. Up key
2. Left key
3. Down key
4. Right key
5. Return key
6. Select
7. TB
8. TA
9. A
10.B
11.Stop/Play



Caution:
1.Can not enter the built-in games when reading disk.
2.For different games,the function keys might be different,the user could get the know-how by trying several times
3.You can download games through PC from this website:www.native32.com into the usb or memory Cards.

MPEG4 Decoding Tehnology

MPEG4 is the widely-applied video image saving and transporting standard,theDVD is designed with MPEG4 file playing function skillfully,the user may not only enjoy the rich video/audio resource on the internet but also breach the limit of watching film on computer only.The user may use PC to download,record or transcribe and produce the MPEG4 disks, the better picture and sound quality could be achieved.

MPEG4 is the fourth version of audio/video standard by moving pictures exqerts group. mpeg1 is the video image compression standard of VCD,MPEG2 is the video image compression standard of DVD or super V. MPEG4 is one of the network video image compression standards,The video/audio file with MPEG4 technology features high compression rate and clear image.Generally,hundred or more OK songs or many films might be saved in one disk with better image quality than VCD or SVCD!

Note: In the market,some disks marked with MPEG4 is real video actually or other formats (such as *rm/*ram/*rmvb/*wmv/*ast),which couldn't be compatible with the international standard MPEG4, they could be played by special software only and couldn't be played by this player.Do identify it in buying disks.

Description for Playing Mp4 Disks

The operation of MP3 disk is same with playing mp4 disk,MP4 disk has video image and auto play is the Default setup for this player ,press stop/return key to return to the menu to facilitate the user to select the Menu.

Features

Available in Black,Grey
Adjustable mounting poles to fit any seat
7" wide(16:9) TFT LCD monitor
Built in IR/USB/SD Function
7"Headrest TFT LCD Monitor with DVD/USB/
SD/Dual IR/FM/Games/Speakers/wireless
remote + joystick
DVD player -Compatible with Multimedia Discs-
DVD,VCD,MP3,CD-R,CD-RW,DVD-RW
Earphone Jack on Faceplate
Color System:PAL/NTSC
Resolution LCD:480 RGBX234
Brightness rating:300 cd/m2
Built in dual channel IR transmitter
Channel A:2.3Mhz(left)-2.8Mhz(right)
Channel B:3.2Mhz(left)-3.8Mhz(right)
Operating Temperature:-20℃ to 50℃
Storage Temperature:-10℃ to 70℃
Environmental Humidity:<90%

Universal headrest with

Pre-installed monitor owner's manual

Congratulations on your purchase of this headrest monitor system.The product is designed and built to deliver excellent video quality and long lasting high performance.For best results please consult a professional mobile electronics installer for application advice or troubleshooting. Please read these instructions throughly before installation.

Installation Instructions

1.Remove the existing headrest the seat.
2.Adjust the posts of the new headrest to fit the holes in the seat where the headrest will be installed. The post can be moved together or one post in each hand,move the posts in right and left movements while pushing them toward each other or away from each other.
3.Insert the cable in the proper hole.Insert the posts into the holes in the seat and carefully work the headrest into position.Make sure the cable is not damaged or pressed.
4.Run the cable down the seat and out to the location of the video source unit(such as a DVD player).
5.Connect the wires as indicated:
a. Red: connect to a switch ed(+)12 volt source (ACC).Use a lead that has(+)12V when the ignition is on or in the ACC position so the monitors turn off when the key is in the off position.Wiring the monitors to the battery could cause your battery to run down when the engine is not running.
b.Black:Connect to a good chassis ground.
c.Reversing the polarity of the red and black leads will damage the monitor.
d.Connect the video input connector to the video output from the source unit(i.e.DVD player).
e.Test the system.

Notice before operation

Safety

- Before operating the product,please check the voltage of your car and it should be consistent with the working voltage of the player.
- Do grasp the powerplug firmly in connecting or disconnecting to the power,do not pull the power line by force.
- The radium emitting light beam used by the product is harmful to eyes,do not dismantle the enclosure without permission and only the professional technicians are allowed to conduct the repair or maintenance.

Placement

- Please operate the product in proper temperature,the storage temperature should be-30℃ to 75℃,and the working temperature should be -20℃ to 50℃.
- To prevent dust falling on the laser head,it shall affect the playing effect,if the head is dusted,please used the laser head cleaning disk to clean.refer to the instructions of purchased cleaning dish for detailed operation.
- It should be damp-proof,crash-poof and pressure-proof.

Dew

In the below conditions,moisture shall be formed on the lens(dew formation):

- Carry the player from the cold place to warm place;
- In the condition of big temperature difference such as at the moment of opening the heating device;
- If the dew is formed,it shall affect the normal work of the player ,and please remove out the disk,lay the player on table for one hour under the condition of connecting to power so as to vapor the moisrure.

Precaudtions for disk

- In order to keep the disk clean,please take the edge of disk and do not touch its surface;
- Do not adhibit any paster or tape on the disk;
- Keep the disk away from direct sunshine or heat source;
- Please place hte disk in the disk box after being used;
- Before playing the disk,if the disk is dirted,please clean it with soft cloth from the center to out;
- Do not use voatile oil and thinner to clean the disk.

Remote Control

Key	Function
1.PBC/Menu	Press the key to return to the root menu in playing DVD disk, and open/close the pbc menu in playing VCD2.0 and SVCD.
2.Power	Power ON/OFF
3.TFT/Menu	Monitor Menu
4.Display	Display the disk information and playing time
5.Left	Direction selecting key/Left
6.Repeat	Multiple modes of repeat play shall be available
7.Setup	DVD Setup
8.Angle	Angle switching key,used for svcd,dvd and mp4 disks With multiple angles only
9.Rewind	Rewind
10.Pause	Play or pause
11.Last	Select the previous
12.Stop	Stop key,press the key to return in playing
13.Figure keys	Number selection
14.DVD/AV	DVD/AV Switching
15.Subtitle	Subtitle switching ,used for SVCD,DVD and mp4 disks with multiple subtitles only
16.Return	Menu Back key
17.Title	Press the key to return to the title menu in playing DVD disk
18.Mute	Open/close the sound
19.Up	Direction selecting key/UP
20.Program	Track programming Play
21.Enter	Confirmation
22.Right	Direction selecting key/Right
23.Down	Direction selecting key/Down
24.USB/SD	USB/SD switching
25.Forward	Fast forward
26.Vol+	Volume +
27.Next	Fast backward
28.Vol-	Volume -
29.Zoom	Zoom in/out,multiple modes
30.Slow	Slow play
31.Audio	Language switching key,used for svcd,dvd and mp4 disks with multiple languages only,channel switchhing key for VCD

Remote Control



Monitor Controls and Features

The monitor is designed to operate in ambient temperature from -20 °C to +50 °C. Do not bump or press on the screen as this may damage the unit, keep the unit away from moisture. Where are the specifications?

The specifications of this product are subject to our modification without notice.



Remark: On the panel of button no. 5 and 7. Short press both are belong to DVD function "-PREV /+NEXT"; Long press both are Volume "-/+" function.

1. Power
2. Source
3. Menu
4. SD
5. Adjust-/Prev
6. USB
7. Adjust+/Next
8. Play
9. Stop
10. Earphone Jack

Install the Pillow



How to use the Adapter tubes



Since the spacing of the mounting holes can vary on different vehicles we supply two adapter tubes (12mm diameter). Use these tubes when the headrest mounting holes in your seat are too large forthe posts of the headrest monitor.

Key parts in front of the player



Notice: Please carefully turns on the display monitor when vehicles start,please to close the display monitor after puts well the small dish as soon as possible,in order to avoid damages to the display monitor.

Poles Installation



① Uncover the leather of the poles position.



② Put the poles in the poles position.



③ Put away the poles aud cover it with the cover.



④ Screw the poles complte.